## **PTS LED SERIES**

### INSTALLATION INSTRUCTIONS

# Williams

### **WARNING:**

- Caution Risk of Shock. This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- Make sure all electrical power is turned off while installing the fixture.
- This luminaire must be adequately grounded for protection against shock hazards and to assure proper operation.
- Disconnect power before servicing.


- LEDs are ESD (Electro Static Discharge) sensitive devices that can be easily damaged if the proper ESD mitigating steps are not taken.
- LEDs are very sensitive to mechanical damage. Caution must be taken to avoid damage to the LEDs.
- ESD or mechanical damage voids all warranties.
- Suitable for dry and damp locations.

#### **BACKVIEWS**


1x4

- (4) 7/8" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (2) 2" KOS
- (3) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" KOS
- (4) 5/16" Mounting holes - (2) 2" Mounting

48-9/16



- STEP 1: Remove diffuser and reflectors.
- STEP 2: Attach fixture(s) to structure using (4) 1/4-20 screws in the mounting holes provided.
- STEP 3: Attach power supply and ground wires using UL listed wire connectors. Ballast disconnect accepts #12 #16 AWG stranded or solid wire.
- FIG 3.1 Make electrical connections in accordance with NEC and local codes.



NOTE: Please consult factory for other driver configurations or emergency driver wiring diagrams.

STEP 4: Re-install reflector(s) into housing and install diffuser.

NOTE: Refer to individual product specification sheets for further information.