PX CORNER BLAST LENS KIT

INSTALLATION INSTRUCTIONS




WARNING:

- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- Make sure all electrical power is turned off while installing the fixture.
- This luminaire must be adequately grounded for protection against shock hazards and to assure proper operation.
- Disconnect power before servicing.
- LEDs are ESD (Electro Static Discharge) sensitive devices that can be easily damaged if the proper ESD mitigating steps are not taken.
- LEDs are very sensitive to mechanical damage. Caution must be taken to avoid damage to the LEDs.
- ESD or mechanical damage voids all warranties.
- Suitable for dry and damp locations.


FOR USE WITH:

PXF – Wash

PXG – Wash



PARTS LIST (INCLUDED)



CORNER BRACE

0

SET SCREW



LENS BRACKET

A

#8 X 1/2 SCREW


LENS

PX CORNER BLAST LENS KIT

INSTALLATION INSTRUCTIONS

- STEP 1: Install PXG/PXF Wash fixture per supplied instructions
- STEP 2: Install corner brace using supplied #8 screws. Do not completely tighten.
 - Pull the corner extension channels together while tightening corner brace screws, keeping corner extensions tightly together. See FIG 2.1.






STEP 3: Install the lens

• 45 degree miter cut is used at the corner. See FIG 3.1






PX CORNER BLAST LENS KIT

INSTALLATION INSTRUCTIONS

STEP 4: Secure brackets

- A. Drill (3) holes per side into the PX channel, 6 holes in total, using 1/8" diameter drill bit. See FIG 4.1 and TABLE 4.1 for drill locations. A right angle drill or drill attachment will be required.
- B. Secure (3) lens brackets to each channel using supplied #8 screws. See FIG 4.1 & 4.2.
- C. Attach lens into lens bracket, securing with #8 set screw. Lenses shall create a butt joint at corner. See FIG 4.3.










FIG 4.3

